




AcoustiPack™

Ultimate Noise Reduction

AP AntecBQE Pack Contents and Fitting Directions

Pack Contents:

The AcoustiPack™ AP AntecBQE contains 16 pieces, of 2 different acoustic materials and an optional washable air filter.



Acoustic Foam



Acoustic Composite

Fitting Directions:

Fit according to the positions indicated, in the numerical order shown from 1 to 17. Where self adhesive is on the reverse of the materials, remove the backing sheet and adhere lightly to clean and dust-free surfaces, making sure that the material is correctly positioned. If you make a mistake - it can be re-applied for a second attempt - but be aware that excessive re-application will cause a deterioration in the adhesive. Once well positioned, press the materials firmly into place.



Ensure you read the important safety information before installing the materials.


Opt = Optional

Note Regarding Part 13:

3½-inch drive bay mounting is shown removed for clarity. Removal may not be required for fitting part 13.

Note Regarding Part 1:

1. Remove the uppermost 5¼-inch drive bay cover to help with access, and turn the case upside down.
2. Peel back only a portion of the self-adhesive backing sheet and fit the front section of this part first. Once in position, fit the remainder of the part.



READ THIS BEFORE I INSTALLING THE MATERIALS!

- ONLY position the materials as directed in the fitting directions and as depicted in the graphics above.
- DO NOT cover any necessary ventilation holes in the case with materials.
- DO NOT position the rear of the case close to a permanent heat source, such as a radiator, or very close to an airflow obstruction, such as a wall. This may inhibit air circulation required for cooling. Leave a gap at the rear of the case of at least 20cm to allow free movement of air in and out of the case.
- DO NOT position materials inside the case in such a way that may inhibit the correct functioning of any internal components, especially cooling fans, disc drives and moving parts. These components require adequate space and ventilation. Whilst every care has been taken to produce a set of materials that will be appropriate for the majority of component configurations, it is the responsibility of the machine builder to position materials appropriately to facilitate normal functioning of internal components.